




SEAWARD

PrimeTest 50



Operating Instructions

PrimeTest 50

Operating Instructions



SEAWARD

Bracken Hill
South West Industrial Estate
Peterlee
Co Durham
SR8 2SW
ENGLAND

Tel: +44(0)191 586 3511

www.seaward.com

sales@seaward.com

service@seaward.com

Part Number 347A550 Revision 5

© 2020 Seaward Electronic Ltd

Limited Warranty & Limitation of Liability

SEAWARD Electronic Limited guarantees this product to be free from defects in material and workmanship under normal use and service for a period of 1 year. The period of warranty will be effective at the day of delivery.

(c) Copyright 2020

All rights reserved. Nothing from this edition may be multiplied, or made public in any form or manner, either electronically, mechanically, by photocopying, recording, or in any manner, without prior written consent from SEAWARD Electronic Limited. This also applies to accompanying drawings and diagrams.

Due to a policy of continuous development SEAWARD Electronic Limited reserves the right to alter the equipment specification and description outlined in this publication without prior notice and no part of this publication shall be deemed to be part of any contract for the equipment unless specifically referred to as an inclusion within such contract.

Contents

1	Important Information.....	4
2	Introduction.....	7
3	Performing Tests.....	8
3.1	Checking a mains power outlet.....	8
3.2	Testing a Class I Appliance.....	9
3.3	Testing a Class II Appliance.....	12
3.4	Testing a mains cord.....	13
4	Specification	15
5	Maintenance	15
6	Battery Check	16
6.1	Battery Replacement	16
7	Service and Calibration	17

1 Important Information

These operating instructions are intended for the use of adequately trained personnel.

The following symbols are used in these operating instructions and on the PrimeTest 50.



Caution, risk of electric shock.

Indicates instructions must be followed to avoid danger to persons.



Caution, risk of danger. The operating

instructions must be adhered to in order to avoid danger.

Before use, ensure unit is clean and dry; visually inspect all leads, connectors, and case. Any damage or wear must be rectified prior to use.

	Part Number
PrimeTest 50 unit	347A910

Standard Accessories	Part Number
Carry Case	71G082
Black Test Lead 1m	347A002
UK IEC mains cord 0.5m	300A002
Operating Instructions	347A550

Optional Accessories	Part Number
230/110V Adaptor	270A076
3 phase adaptor - 16A 4 pin 415V	209A910
3 phase adaptor - 16A 5 pin 415V	209A911
3 phase adaptor - 32A 4 pin 415V	209A912
3 phase adaptor – 32A 5 pin 415V	209A913
NiMH Batteries and charger	339A950

Full details and specifications can be found at www.seaward.com or by calling Seaward Sales on 0191 586 3511.




Figure 1. PrimeTest 50 Front View




Figure 2. PrimeTest 50 End View

2 Introduction

The PrimeTest 50 is a hand held battery powered unit suitable for carrying out electrical safety checks on:

- Class I appliances
- Class II appliances
- IEC mains leads
- Extension leads
- Mains outlet wiring

Numbers shown in circles e.g. ① refer to figure 1 and figure 2 on page 6.

Test connections on the PrimeTest 50 are:

- Mains socket on front panel ① for connecting the appliance under test.
- 4mm socket on end panel ⑥ for earth test probe
- IEC socket on end panel ⑦ for mains cord testing.

User Interface

The LCD display ⑤ shows test progress, results for individual tests and the overall test result for an appliance or mains cord.

Tests are initiated using the three push buttons:

Power ON/OFF = ② + ③ until a beep is heard

Class I appliance test = ②

Class II appliance test = ③


Cord / extension lead test = ④

Note: The PrimeTest 50 will automatically switch OFF after approximately 3 minutes if no keys are pressed. The auto switch-off is disabled during a power socket test.

A long press on the test key ②, ③ or ④ will cause a tone and the 500V warning symbol to illuminate. When released the test will start and insulation resistance carried out at 500v, but the tester will then default back to 250v for the next test. A normal short press will perform the insulation resistance test at the default 250v.

3 Performing Tests


Press keys ②+③ to switch on the PrimeTest 50. When the unit is ready the display will be as shown below.




3.1 Checking a mains power outlet

Connect the IEC power cord to the PrimeTest 50 socket ⑦ and plug into the mains power outlet to be tested.

If the mains socket wiring is correct the display will show.



If there is a fault with the socket wiring this is indicated by the display below.



In the event of a failure, disconnect the PrimeTest 50 from the supply and rectify the fault.




Do not leave the PrimeTest 50 permanently connected to a mains supply.

The auto switch-off function is disabled when the PrimeTest 50 is connected to a live mains socket. The unit will beep continually after 3 minutes to remind the user to disconnect from the mains socket.


3.2 Testing a Class I Appliance

- Visually inspect the appliance and mains cord for signs of damage.
- If the appliance passes a visual inspection proceed with the electrical tests.
- Plug the earth test lead into the 4mm socket ⑥ on the PrimeTest 50 end panel.
- Plug the appliance into the PrimeTest 50 front panel mains socket ①
- Connect the earth test probe to an exposed metal part on the appliance.
- If the Appliance under test has an ON/OFF switch, make sure it is in the ON position.
- Press the Class I test key ②
- The PrimeTest 50 will now test the continuity of the protective earth.

- If the measured value is outside acceptable limits a cross is placed next to the **Earth Cont** enunciator, a FAIL is indicated and the test sequence is halted.




- If the measured value is within acceptable limits a tick is placed next the **Earth Cont** enunciator.




- The unit will proceed with the Insulation test at 250V.
- If test key ② has had a long press this will cause a tone and the 500V warning symbol to illuminate. When released the test will start and insulation resistance carried out at 500v, but the tester will then default back to 250v for the next test.

Note: The power switch on the appliance under must be in the ON position to perform an insulation test. If no appliance is detected the PrimeTest 50 will display the following.




- Check that the appliance power switch is in the ON position. The test will automatically proceed if the appliance power switch is placed in the ON position.
- If the **Check Connections** enunciator remains on the display, the load presented by the appliance may be too small for the PrimeTest 50 to detect. In this case, press the test key ② to continue.
- If the Insulation Resistance is greater than the acceptable limit a tick is placed next to the **Insulation** enunciator and the **PASS** enunciator is illuminated.



3.3 Testing a Class II Appliance


- Visually inspect the appliance and mains cord for signs of damage.
- If the appliance passes a visual inspection proceed with the electrical tests.
- Plug the earth test lead into the 4mm socket ⑥ on the PrimeTest 50 end panel.
- Plug the appliance into the PrimeTest 50 front panel mains socket ①
- Connect the earth test probe to an exposed metal part on the appliance.
- If the Appliance under test has an ON/OFF switch, make sure it is in the ON position.
- Press the Class II test key ③
- The PrimeTest 50 will now test Insulation Resistance at 250V.
- If test key ③ has had a long press this will cause a tone and the 500V warning symbol to illuminate. When released the test will start and insulation resistance carried out at 500v, but the tester will then default back to 250v for the next test.

Note: The power switch on the appliance under must be in the ON position to perform an insulation test. If no appliance is detected the PrimeTest 50 will display the following.



- Check that the appliance power switch is in the ON position. The test will automatically proceed if the appliance power switch is placed in the ON position.


- If the **Check Connections** enunciator remains on the display, the load presented by the appliance may be too small for the PrimeTest 50 to detect. In this case, press the test key ③ to continue.
- If the Insulation Resistance is greater than the acceptable limit a tick is placed next to the **Insulation** enunciator and the **PASS** enunciator is illuminated.



3.4 Testing a mains cord

- Visually inspect the appliance and mains cord for signs of damage.
- If the appliance passes a visual inspection proceed with the electrical tests.
- Plug the mains lead under test into the IEC socket ⑦ and the front panel mains socket ① on the PrimeTest 50.
- Press the cords test key ④
- The PrimeTest 50 will now test the continuity of the protective earth.
- If the measured value is outside acceptable limits a cross is placed next to the **Earth Cont** enunciator, a FAIL is indicated and the test sequence is halted.
- If the measured value is within acceptable limits a tick is placed next the **Earth Cont** enunciator.
- The unit will proceed with the Insulation test at 250.

- If test key ③ has had a long press this will cause a tone and the 500V warning symbol to illuminate. When released the test will start and insulation resistance carried out at 500v, but the tester will then default back to 250v for the next test.
- If the Insulation Resistance is lower than the acceptable limit a cross is placed next to the **Insulation** enunciator and the test sequence is halted.
- If the Insulation Resistance is greater than the acceptable limit a tick is placed next to the **Insulation** enunciator.
- The unit will proceed with the wiring test, checking the live and neutral conductors for short or open circuits or reversed connections.
- If the wiring is correct a tick is placed next to the cord enunciator and a pass is indicated for the sequence.



4 Specification

Earth Continuity

Pass Limit	0.2Ω
Accuracy*	± 0.03Ω
Test current	200mA minimum
Test voltage	9V nominal

Insulation resistance

Pass Limit	1.0MΩ CLI, 2.0MΩ CL II 2.0MΩ Mains cord
Accuracy	± 0.1MΩ
Test voltage	250/500V
Test current	>1mA into 500kΩ
Test current	<2mA into 2kΩ

Cord Test

Earth continuity, insulation resistance as above.
Check for Line and Neutral open circuit, short circuit or reversed polarity.

*When used with Seaward test lead, Part Number 347A002

Environmental rating

IP40

Operating temperature range 0°C to 40°C, without moisture condensation.

Storage temperature range -25° to 65°. Batteries should be removed prior to storage.

Overvoltage category 300V CAT II

5 Maintenance

Clean only with a dry cloth; do not use solvents. Before use, ensure unit is clean and dry; visually inspect all leads, connectors, and case. Any damage or wear must be rectified to preserve user safety.

Check the battery contacts and compartment are free of electrolytic contamination. Any contamination of the battery contacts or compartment should be cleaned with a dry cloth.

6 Battery Check

The PrimeTest 50 is powered from a 6 AA cells which are checked before a test is performed. When the battery voltage is low the **Low Batt** enunciator is illuminated. The unit will continue to perform within specification for a limited number of tests, dependent upon the type of the batteries fitted.

When the battery voltage reaches a level where the performance is affected the **Low Batt** enunciator will flash and all test keys are disabled. The batteries must be replaced.

6.1 Battery Replacement



Before opening the PrimeTest 50 ensure that it is disconnect all test leads.

- Switch off the unit by pressing and holding keys ② and ③.
- Disconnect the black test lead from 4mm test socket ⑥.
- Disconnect the IEC mains cable from the IEC socket ⑦.
- Disconnect the EUT mains cable from the EUT socket ①.
- Place the PrimeTest 50 face down, release the captive screw in the battery compartment cover.
- Remove the battery compartment cover.
- Remove the discharged batteries.
- Insert the replacement batteries into the battery compartment ensuring that the battery polarity matches the marking on the inside of the battery compartment.
- Relocate the battery cover over the battery compartment and fasten in position with the battery cover captive screw.

7 Service and Calibration

To maintain the specified accuracy of the measurement results, the instrument must be recalibrated at regular intervals by either the manufacturer or an **authorised Seaward Service Agent**. We recommend a recalibration period of one year.

For help or advise on Service and Calibration contact:

Service Department
Seaward Electronic
Bracken Hill
South West Industrial Estate
Peterlee
Co Durham SR8 2SW
England

Tel: 0191 586 3511

Email: service@seaward.com

Web: www.seaward.com