
Digital Microhmmeter Type D07

Operating Instructions



Bracken Hill, South West Industrial Estate,
Peterlee, Co. Durham SR8 2SW. England.

Tel: +44 (0)191-586 3511

Fax: +44 (0)191-586 0227

www.seaward.com

sales@seaward.com

Limited Warranty & Limitation of Liability

CROPICO guarantees this product for a period of 1 year. The period of warranty will be effective at the day of delivery.

© Copyright 2016

All rights reserved. Nothing from this edition may be multiplied, or made public in any form or manner, either electronically, mechanically, by photocopying, recording, or in any manner, without prior written consent from CROPICO. This also applies to accompanying drawings and diagrams.

Due to a policy of continuous development CROPICO reserves the right to alter the equipment specification and description outlined in this publication without prior notice and no part of this publication shall be deemed to be part of any contract for the equipment unless specifically referred to as an inclusion within such contract.

Disposal of Old Product

This product has been designed and manufactured with high quality materials and components that can be recycled and reused.

When this symbol is attached to a product it means the product is covered by the European Directive.

Please familiarise yourself with the appropriate local separate collection system for electrical and electronic products.

Please dispose of this product according to local regulations. Do not dispose of this product along with normal waste material. The correct disposal of this product will help prevent potential negative consequences for the environment and human health.

Contents

Supplied Accessories:	5
1. SAFETY	6
WARNING!	6
2. INTRODUCTION	7
Display range 6000	7
3. MEASURING PRINCIPLE	7
4. CASE DESIGN	7
5. MAINTENANCE	7
6. BATTERY CHARGING	8
7. TECHNICAL DATA	9
8. DESCRIPTION OF CONTROLS	11
Range Selection:	11
Error & Status Lamps	12
9. METHODS OF MEASUREMENT	13
10. POWER UP	15
11. MEASUREMENT	15
Over-Range	16
12. REMOTE	16
13. PRINTER OUTPUT	16
14. PROTECTION	18
15. CALIBRATION PROCESS	18
16. EQUIPMENT REQUIRED	18
17. PREPARATION	18
18. CALIBRATION	19
19. VERIFICATION	20
20. USING DISCRETE RESISTANCE STANDARDS	21
21. SPECIAL OPERATION - CAL RESET	23
22. AVAILABLE ACCESSORIES	24

IMPORTANT NOTE

These Operating Instructions are intended for the use of Competent Personnel.

Instruments are delivered ready for immediate use; no extras are required.



Caution, risk of electric shock. Indicates instructions must be followed to avoid danger to persons.



Caution, risk of danger. The operating instructions must be adhered to in order to avoid danger.

Supplied Accessories:

- 1 Set of test leads
- 1 Mains cord
- 1 Operating Instructions (English)

When unpacked, inspect for physical damage and report any defects immediately in writing, retaining packaging materials for inspection. Before placing into service, ensure mains voltage is correct, instruments are normally supplied for 240V 50Hz. Other voltages may also be selected according to the chart in section 5, (Maintenance). Be sure to also change the fuse to the correct type.

1. SAFETY

This apparatus has been designed and tested in accordance with EN61010, entitled “Safety requirements for electrical equipment for measurement, control and laboratory use”, and has been supplied in a safe condition. The present instruction manual contains information and warnings which must be followed by the user to ensure safe operation and to retain the apparatus in safe condition.

Before switching on the apparatus, make sure that it is set to the voltage of the power supply. The mains plug shall only be inserted in a socket outlet provided with protective earth contact. The protective action must not be negated by the use of an extension lead without a protective conductor.

WARNING!



If the DO7 is used in a manner not specified by these operating instructions then the protection provided may be impaired



Always inspect the apparatus and associated leads and accessories for any damage. Do not use if there are signs of damage. Only use the correct leads supplied with the DO7.



Whenever it is likely that the protection has been impaired, the apparatus shall be made inoperative and be secured against any unintended operation and returned to our factory or Agent for rectification.



Any interruption of the protective conductor inside or outside the apparatus, or disconnection of the protective earth terminal is likely to make the apparatus dangerous. Intentional interruption is prohibited.



The apparatus must be disconnected from all voltage sources before mains inlet fuse replacement is attempted.



Make sure that only fuses with the required current rating and of the specified type are used for replacement. The use of makeshift fuses and the short-circuiting of fuse holders is prohibited.



DO7 has been designed to operate in a dry environment.



Do not open DO7, no user serviceable parts

2. INTRODUCTION

The DO7 is an accurate bench/portable Digital Ohmmeter for the measurement of resistance in the range $0.1\mu\Omega$ to 60Ω . It offers you the four terminal resistance measurement method to eliminate the effect of lead resistance. The measured values are displayed on a 4-digit LCD display; an overflow of the selected range is also indicated.

Display range 6000

Simple push-button selection of the range required, ensures that the DO7 may be easily used by unskilled personnel. Error and status warnings are illuminated when appropriate. The utmost care has been taken to ensure that the ohmmeter will withstand an accidental mains voltage applied to the measuring terminals, but it is not recommended that voltage should be applied.

3. MEASURING PRINCIPLE

The measurement is true 4 terminal, using the Kelvin principle. A stable current is produced across the resistance to be measured via the C terminals, and the voltage drop across the Rx is measured at the P terminals. This potential drop is then compared against the voltage drop across internal standards. The ratio of these is then converted to the resistance value of Rx and displayed in ohms on the digital display. High accuracy and long term stability is achieved by using our own manufactured internal resistance standards.

4. CASE DESIGN

The case is ruggedly constructed from an ABS/polycarbonate alloy, coloured safety yellow. A strong internal sub-frame ensures that the DO7 will withstand the harshest of environments. The front panel is a reverse printed polycarbonate overlay with clear and unambiguous text.

5. MAINTENANCE

Normally no maintenance is required other than cleaning with a dry cloth. Avoid aggressive detergents or solvents.

CAUTION: Before any maintenance, the instrument must be disconnected from the mains supply and all power sources. In the event of a fault occurring, the instrument should be returned to our factory or Agent. A mains fuse is fitted to the mains inlet socket on the front panel and should be replaced if necessary.

CAUTION: Disconnect mains lead and all connecting leads, before removing fuse holder. Replace only with the correct fuse type, ie. according to the following chart.

Line Voltage Selection	Range VAC 47-63Hz	Fuse (250V) IEC 127 5 x 20 mm
100V 120V	87-110V 104-132V	1.25A (T)
220V 240V	191-242V 209-264V	630mA (T)
Maximum Input Power: 40VA		

There are no other user replaceable fuses.

6. BATTERY CHARGING

The DO7 has built-in rechargeable sealed lead acid batteries which are fully charged when delivered. To ensure good service life from the batteries, the DO7 incorporates a sophisticated battery management system. To indicate the state of charge, 8 LEDs indicate the remaining battery capacity in % of full charge. These LEDs are arranged in a gas gauge style.

The battery charger is built in and the instrument may be connected to 100/120/220 or 240 volts supply. The appropriate voltage setting must be selected on the inlet socket and the correct fuse inserted. The LINE LED will illuminate on the front panel to indicate when the mains supply is connected.

Charging is automatically controlled with built-in protection circuits eliminating the possibility of over-charging. The display will blank when the battery voltage is too low to sustain measurements, and the battery state indicators show the current state of charge. The DO7 will operate whilst charging on all ranges except the bottom two, and an additional error of approximately 8 digits may be observed with mains supply connected. The lower ranges have a larger measuring current than can be supplied by the charger, and therefore batteries must be fully recharged before use. The batteries will recharge in approximately six hours, and the DO7 lid should be open to allow for maximum ventilation.

IMPORTANT Always connect instrument to mains supply after use and top up battery. Instruments should be stored with batteries fully charged, and when stored for long periods the batteries should be recharged each month.

Should the batteries become deeply discharged due to either being stored with the instrument switched on, or being left for long periods without charge, then it may appear that no charging is taking place when first connected to the mains supply. The Line LED will light but fast charge LEDs will not. The internal charger will automatically sense the battery state and will trickle charge with a very low current to restore the batteries before automatically switching to fast charge. This low current charge may take up to 20 hours to restore the batteries. Continuous charging will not damage the batteries and will, in fact, keep them in best condition.

7. TECHNICAL DATA

4 digit, LCD 0.8" height; 6000 count with automatic decimal point and error warning lamps

Suitable for indoor operation only.

Maximum altitude: 2000m

Operation temperature: 0°C...+40°C without moisture condensation

Storage temperature: -20°C...+50°C

Relative humidity: up to 90%

MAINS supply voltage fluctuations for 230/240V systems: 206V to 256V

Wet locations: None

Pollution degree: 2

IP Rating: IP40

Size (mm.) 343 x 327 x 15

Mass 8.3 Kgs

Environmental conditions

DO7 has been designed to perform measurements in dry conditions.

Maximum barometric elevation at which measurements can be recorded is 2000m.

Protective system IP40 according to IEC60529.

Measurement

Resistance	True four-terminal measurement with fixed dc measuring currents.
Measuring time	Approx. 0.5 seconds
Polarity	Forward and reverse measurement current may be selected, plus average mode which automatically displays the average value of positive and negative polarity measurement.


Range	Resolution	Typical Current	Uncertainty At 20°C ± 5°C, 1 Year	Temperature Co-efficient/°C*
60Ω	10mΩ	1mA	±(0.15% Rdg + 0.05% FS)	40 ppm Rdg + 30 ppm FS
6Ω	1mΩ	10mA	±(0.15% Rdg + 0.05% FS)	40 ppm Rdg + 30 ppm FS
600mΩ	100μΩ	100mA	±(0.15% Rdg + 0.05% FS)	40 ppm Rdg + 30 ppm FS
60mΩ	10μΩ	1Amp	±(0.15% Rdg + 0.05% FS)	40 ppm Rdg + 30 ppm FS
6mΩ	1μΩ	10Amp	±(0.2% Rdg + 0.1% FS)	40 ppm Rdg + 30 ppm FS
600μΩ	0.1μΩ	10Amp	±(0.2% Rdg + 0.2% FS)	40 ppm Rdg + 250 ppm FS

Ranges and Accuracy

***NOTE** Temperature coefficient to be added to uncertainty when operating outside the range 15 to 25°C

NOTE: Measurements on the lowest range 600μΩ will have an additional zero offset of up to 20 digits, if the measuring current is applied for long periods. This offset can be eliminated by using the average measuring mode.

8. DESCRIPTION OF CONTROLS



ON/OFF Power Switch

Powers the instrument ON and OFF. The switch does not disconnect from the mains supply.

Range Switches:

The 6 ranges may be selected manually by simply pressing the desired range button. The selected range will be indicated by an LED and over-range will be indicated by the display reading - - - -.

Calibration

Set to RUN position for normal operation. Turn to CAL for calibration.

RS232/Printer socket

For connection to a printer

MAINS Socket

Connection and disconnection of the mains supply. Mains inlet is equipped with user replaceable fuse. Refer to the description on the instrument and in the operating manual for correct fuse type and rating.

Battery status indicator

Indicates batteries charge status.

4 digits LCD display

Displays measured resistance value.

Error & Status Lamps

These LEDs will light to indicate the instrument status.

- LINE: Mains supply is connected to the instrument.
- CAL: Calibration mode has been initialised by the key switch and the instrument is in calibration mode.
- O/C: One of the measuring leads is open circuit
- LEAD: Too high resistance, or not connected to test sample correctly, or the internal protection fuse is open circuit. The lamp will always light in standby mode.

Measuring terminals

Used for 4-wire resistance measurement. Terminals marked as C1 and C2 carry current, whereas terminals marked as P1 and P2 are used for sensing of the voltage drop across the measured resistance.

The measuring current polarity may be selected from the front panel. The display will indicate either + or - to denote the current flow. This is particularly useful when evaluating circuits with thermal emf or where diode effects can influence the measurement. For measurements where thermal emf can cause a large measuring zero error, we have provided an additional automatic average button. When pressed, the measuring current will automatically be reversed and the average value displayed, thus eliminating the need for external computations. This average facility will also adjust the measurement time automatically, thus giving the fastest possible measurement even on inductive circuits.

The +ve and -ve lamps will light to indicate that the current polarity is changing. For very unstable values where the average mode is unable to establish a stable reading, the averaging will be aborted after approximately 25 seconds and the display will indicate - - - - A new average cycle will be automatically initialised.

9. METHODS OF MEASUREMENT

9.1 Ohmmeter Connections

The Digital Ohmmeter type DO7 employs a four wire method of measurement, ie. it is necessary to make four connections to the resistor under test. The instrument is supplied with four leads; two for the potential connections which are made across the test resistor at the points between which the resistance is to be determined; and two for the current connections which connects the test resistor to the supply circuit.

- a) Connect the black leads to the C1 and P1 terminals, and the red leads to terminals C2 and P2.
- b) Clip on to the resistor under test (fig. 9-1). Cleanliness is important and if the sample is not clean, a rub with an abrasive paper to remove oxides is recommended.
- c) It is not always possible to use the combined current and potential clips, in which case test leads with spade tags or special test fixtures may have to be made for the user to suit particular applications.
- d) Fig. 9-2 illustrates connections to various types of test resistors.
- e) When measuring 4-terminal resistance standards, do not use the combined current and potential probes. Make four separate connections to the current and potential terminals.

Fig. 9.1 Combined current and potential probes





Fig. 9.2 Various types of resistors



10. POWER UP

When the DO7 is first switched on, a lamp test is automatically performed. All display segments are illuminated followed by each LED lighting in sequence. NOTE the LOCK LED is not fitted and will therefore NOT light. The microprocessor checks for correct internal operation and indicates "P" if all tests pass O.K. At the same time the software version will be displayed and held for approximately 2 seconds. The display will typically read "P 1.1". Should the internal checks indicate an error, then the display will read "HELP". Contact our Service Department or your local agent for assistance.

The DO7 will perform an automatic zero sequence and finally sets to the following default start-up mode ready for use. The selected measuring range will be 60Ω, and the DO7 will then be in stand-by mode.

11. MEASUREMENT

Connect the resistance to be measured (Rx) to the measuring terminals in accordance with the diagram on the instrument panel. Select the range required, the measurement mode, ie. +, - or average. The LED lamp will light to indicate which buttons are active. To initialise the measurement, press and hold the ON button, the measurement will cease once this button is released and the instrument will return to the STANDBY state. Should you wish to initialise a continuous reading, then press the LOCK + ON buttons. The measurement will continue until the STANDBY button is pressed or the ON button pressed again. An audible BLEEP will sound during this time to warn the operator that measurement is still in progress, and up to 10 Amps measuring current is draining the batteries.

DISPLAY HOLD FUNCTION

This works as follows:-

1. When returning to the STANDBY condition the LAST measured value will remain on DISPLAY for 30 SECONDS and then blank.

This occurs when:

- Pressing the STBY key, or
 - Releasing the momentary external footswitch.
2. Pressing any key (except LOCK) during the 30 second period will force the display to blank and allow normal operation to resume. It is recommended that the STBY key be pressed to carry out this function.

Over-Range

The display will indicate - - - -.
Select a higher range.

Open Circuit Lead

O/C LEAD will be displayed and the display will indicate - - - - if the instrument detects that the lead resistance is too high. The C terminals are checked for compliance voltage. If all connections are confirmed to be correct and the O/C LED is still active this may indicate that the internal protection fuse is open-circuit or an internal fault has developed. Measurement should not be made if this warning message is displayed and the device should be returned for repair. When in STANDBY mode this LED will always be lit.

Connections

When making good quality measurements, it is important to ensure that all measuring leads are in good condition, and less than 0.2Ω resistance.

It should also be noted that some spade tags and crocodile clips can produce high thermal emfs when warmed, particularly nickel-plated brass types. This can cause problems when, for example, connecting to hot motor windings. The solution is to use plain copper or brass connections keeping them clean and oxide-free.

12. REMOTE

If a footswitch or other similar external switch is plugged into the REMOTE socket, it will behave as an ON key. This feature is particularly useful when used with the PRINT LAST function to enable "hands free" operation during measurement, with the results printed on an external printer. For switch connections see page 13.

13. PRINTER OUTPUT

The print format will be as follows:

SIGN	VALUE	UNIT (measuring mode)
example:	+ 600.0 m Ω	(+ve)
	- 600.0 m Ω	(-ve)
	600.0 m Ω	(Ave)

The value printed will be followed by a line feed carriage return.

Should the instrument display read over-range then the value will be printed as - - - -
For cable connection details see page 14.

Print All

All measured values will be sent to the printer port (RS232) when “ON”. This key toggles ON/OFF.

Print Last

The last measured value only will be sent to the printer port (RS232). This is defined as the last value measured when switching from “ON” to “STBY”. This key toggles ON/OFF.

Baud Rate

This key will display the currently set value when pressed. To change the value, press CLE to clear and then use the keyboard to enter the new value, finishing with OK. If the new entered value is a valid rate, then it will be stored and retained in the NVRAM. If it is invalid a long bleep will sound and it will reset to the last value. The valid Baud Rates are: 75, 110, 150, 300, 600, 1200, 2400, 4800, 9600, 19200. The format is fixed at 8-bit data, 1 start bit, 1 stop bit and no parity.

14. PROTECTION

Do not apply voltages exceeding 33V ac or 50V dc to the test terminals!

Always check the mains lead for any signs of wear or damages. Should this occur reject the lead.

15. CALIBRATION PROCESS

This procedure describes the standard calibration method for the DO7 Ohmmeter using Cropico Calibration Standard Type MTS2. If discrete resistance standards are to be used instead, refer to section 21 before proceeding.

If the calibration stores are to be pre-set or erased, use the special operation described in section 21 (CAL RESET).

CAUTION


The DO7 will be factory-calibrated to its full accuracy when delivered and any recalibration by the user will invalidate this initial calibration. The user should therefore be certain that only authorised and competent personnel are permitted access to the calibration facility, which is key protected.

16. EQUIPMENT REQUIRED

Cropico Calibration Standard Type MTS2
Set of 2 low thermal emf leads
Set of 2 general purpose leads (10A rating)
Calibration key no. 901

17. PREPARATION

- 17.1** Ensure all retaining screws are fitted.
Place unit in temperature controlled environment for a minimum of 4 hours.
Ensure batteries are fully charged.
- 17.2** Connect each of the four DO7 terminals to the equivalent terminals on the calibration Standard. It is essential that low thermal emf leads are used for the P1 and P2 leads (see Fig.17.1 for the preferred setup).



- 17.3** The DO7 is powered by internal batteries and these should be fully charged before carrying out calibration. The mains charger can be left connected, if desired.
- 17.4** Set the calibration rig to 40Ω, Zero.
- 17.5** Turn the DO7 power ON. If the “HELP” message is displayed, carry out the CAL RESET operation of section 21 before continuing.
- 17.6** Leave for a few minutes to stabilise.
- 18. CALIBRATION**
- 18.1** Insert the calibration key into the panel switch and turn to CAL. The CAL LED should light up.
- 18.2** Set the calibration Standard to 40Ω, Zero.
- 18.3** Set the DO7 to 60Ω range, +ve, and press LOCK+ON.
- 18.4** When the reading has settled, press KYB. The display should read 0. Press OK. The LED should light up for about 3 sec. The reading should now be 0.00 +/-1 digit. If not, repeat this step.
- 18.5** Set the calibration Standard to +FS.
- 18.6** When the reading has settled, press KYB. Enter the value 40 using the keypad and press OK. The LED should light up for about 3 sec. The reading should now be 40.00 +/-1 digit. If not, repeat this step.
- 18.7** Repeat steps 18.2 thru' 18.6 for the remaining ranges.
- 18.8** Turn the panel switch to RUN and remove the key.

19. VERIFICATION

19.1 Ensure that the panel switch is set to RUN and the calibration key is removed.

19.2 Set the calibration rig to 40Ω , Zero.

19.3 Set the DO7 to 60Ω range, +ve, and press LOCK+ON. Wait for the reading to settle.

The reading should be 0.00 ± 1 digit. Note the actual reading in the Calibration Test Results sheet.

19.4 Set the calibration rig to +FS and wait for the reading to settle.

The reading should be 40.00 ± 1 digit. Note the actual reading in the Calibration Test Results sheet.

19.5 Set the DO7 to -ve and wait for the reading to settle.

The reading should be -40.00 ± 1 digit. Note the actual reading in the Calibration Test Results sheet.

19.6 Set the DO7 to AVE and wait for the reading to settle.

The reading should be 40.00 ± 1 digit. Note the actual reading in the Calibration Test Results sheet.

19.7 Reset the DO7 to +ve. Set the calibration rig to 4Ω , +FS and wait for the reading to settle.

The reading should be 4.00 ± 1 digit. Note the actual reading in the Calibration Test Results

19.8 Set the calibration rig to $400m\Omega$, +FS and wait for the reading to settle.

The reading should be 0.40 ± 1 digit. Note the actual reading in the Calibration Test Results sheet.

19.9 Set the calibration rig to $40m\Omega$, +FS and wait for the reading to settle.

The reading should be 0.04 ± 1 digit. Note the actual reading in the Calibration Test Results sheet.

19.10 Repeat steps 19.2 through 19.6 for the remaining ranges.

19.11 Turn the DO7 power OFF and remove the test leads.

19.12 Affix a calibration seal label to the instrument.

19.13 Sign and date the Calibration Test Results sheet.

*** END OF NORMAL CALIBRATION PROCEDURE ***

20. USING DISCRETE RESISTANCE STANDARDS

20.1 Discrete, 4-terminal resistance standards may be used in place of the Cropico Calibration Standard. The standards must have an uncertainty better than 0.01% if the full calibration accuracy is to be achieved. Full consideration of the DO7 measuring current must also be taken into account when selecting the standards. The DO7 can be calibrated to standards between 1000 and 6000 digits for each range using the KYB entry. However, full accuracy will only be achieved if standards of 4000 to 6000 digits are used. The following nominal standards are recommended:

40, 4, 400m, 40m, 4m and 400uΩ

20.2 In all measurements the P1 and P2 terminals are conventionally connected. Bear in mind that thermal emfs may be present. The DO7 is particularly sensitive to these on the 600uΩ range.

20.3 For FS measurements, connect the C1 and C2 leads in the conventional manner (see Fig 20.1).

20.4 For ZERO measurements, connect the C1 and C2 leads to the C2 terminal of the standard (see Fig 20.2).

FULL SCALE CALIBRATION




Fig. 20.1

ZERO CALIBRATION





Fig. 20.2

*** END OF TEST PROCEDURE ***

SPECIAL OPERATION - CAL RESET

- 21.1** This part of the procedure is used to pre-set the calibration memory to a default condition. It will erase all previous calibration data. With Ver 1.X software, this feature can only be used if a calibration memory failure has been detected. This test is performed at power-up and failure is indicated by the HELP message.
- 21.2** Turn the DO7 power ON. Wait for the display test to complete and the HELP message to appear.
- 21.3** Insert the calibration key into the panel switch and turn to CAL. The CAL LED on the front panel should light up.
- 21.4** Press CLE. The LED should light up for about 1 sec.
- 21.5** The HELP message should now be replaced by the normal display.
- 21.6** Turn the panel switch to RUN and remove the key.

REMOTE START

22. AVAILABLE ACCESSORIES

LEADSETS

HSO1	Duplex Handspikes with 3 metre leads
HSO1-RS	Duplex Handspikes as HSO1 but with remote start button fitted
HSO2	Duplex handspikes with 3 metre and 15 metre leads
HSO2-RS	Duplex Handspikes as HSO2 but with remote start button fitted
LSO3	Large Kelvin clips with 3 metre leads – accept cables and bars up to 38mm diameter
LSO4	As LSO3 but with 3 metre leads and 15 metre lead lengths

OTHER ACCESSORIES

CO2	1 Metre Cable Clamp – Metal Base
CO2A	Cable Clamp with Metal Base, for larger cables
CH01	Concentric Handspikes
MTS2	Calibration Standard
CO3	Cable Clamp with incorporated Water bath
270A951	Carry Case for leads

For Technical Support Contact:

Tel: +44 (0) 191 587 8718

For Service and Calibration Contact:

Service Department
Seaward Group
Unit 11
Bracken Hill
South West Industrial Estate
Peterlee
Co Durham
SR8 2LS
England

Tel: +44 (0) 191 587 8739
Fax: +44 (0) 191 587 8737
E-mail: service@seaward.co.uk

CROPICO is a division of



Additional Products From Cropico

DIGITAL OHMMETERS
RESISTANCE BRIDGES
RESISTANCE DECADE BOXES
RESISTANCE STANDARDS
DIGITAL THERMOMETERS
THERMOCOUPLE SIMULATORS
PT100 SIMULATORS
INSULATION TEST SETS
UNIVERSAL CALIBRATORS
HIPOT TESTERS
ELECTRICAL SAFETY TESTERS



Phone, fax or e-mail for further information on the above or for a copy of our general catalogue:

Phone: +44 (0) 191 586 3511
Fax: +44 (0) 191 586 0227
E-mail: sales@seaward.com
Website: www.seaward.com

