How to turn the Primetest 50 on/off?

To turn on the PT 50, press and hold both the class 1 and 2 buttons.

If you require more help, please contact us at https://www.seaward.com/login/enquire/.

15-18 Bracken Hill, South West Industrial Estate, Peterlee, County Durham, SR8 2SW, United Kingdom
t: +44 (0) 191 586 3511 | f: +44 (0) 191 586 0227 | e: sales@seaward.com
seaward.com