



**SEAWARD**  
ELECTRICAL SAFETY TESTING  
& MEASURING.

## How to turn the Primetest 250 on/off?

To turn on the PT 250, press and hold both the class 1 and 2 buttons.

If you require more help, please contact us at  
<https://www.seaward.com/sitemap/enquire/>.