



How do I test RCD's if my tester does not have the option to do so?

When checking an RCD it is recommended that the RCD is tested with an RCD test instrument, and the instrument should operate in accordance with operating standards for RCD's not exceeding 150 mA in table 10.5 of the IET Code of Practice 5th Edition.

If you require more help, please contact us at <https://www.seaward.com/gb/enquiry/>.