

## How to setup the Supernova tester so it prints after test?

To be able print after the test has been completed, you will need to follow the steps below:

- 1. MAIN MENU
- 2. SETUP
- **3. SYSTEM CONFIGURATION**
- 4. AFTER TEST: Select a setting ciontaining DOWNLOAD

If you require more help, please contact us at <a href="https://www.seaward.com/cms/enquire/">https://www.seaward.com/cms/enquire/</a>.