



**SEAWARD**  
ELECTRICAL SAFETY TESTING  
& MEASURING.

## My PV 150 is displaying an error message “ER” followed by a number?

Normally points to a component failure (usually a relay) that isn't repairable by the user. Send unit back to Seaward for further investigation.

If you require more help, please contact us at <https://www.seaward.com/gb/enquire/>.