



What does the "Lo Load" message indicate on the PrimeTest 100?

The "Lo Load" warning generally comes up when the appliance is not turned on. If it is turned on then just press the test button again to perform the test.

If the appliance has an electronic switch or can't be turned on then a leakage test may be more suitable.

If you require more help, please contact us at <https://www.seaward.com/sitemap/enquire/>.