My PV 200/210 is displaying an error message “ER” followed by a number?

Normally points to a component failure (usually a relay) that isn’t repairable by the user. Send unit back to Seaward for further investigation.

If you require more help, please contact us at https://www.seaward.com/us/enquire/.