

How do I install PATGuard 3 on a Standalone PC?

This How to guide is to help if you are trying to install PATGuard 3 on a standalone PC. Please note, you need to be an Administrator on the PC to do this.

Installing on a standalone PC

1. Once you have downloaded PATGuard 3, double-click the downloaded file to install PATGuard 3 on your system. Click Next > on the following screen to start the installation process.



2. Review the Licence Agreement and click Next > to continue.



3.For a standalone PC select Standalone PC and click Next > to continue.

jb Setup - PATGuard 3	
Install Type Please choose installation type.	3
If you want to use PATGuard on a single computer select Standalone To use in a networked environment select Network Install (Network install cannot be installed to Program Files)	PC.
Network Install	
Standalone PC	
< Back Next >	Cancel

4.Either leave the installation directory as the default or change it if you wish and click Next > to continue.

15 Setup - PATGuard 3	X
Select Destination Location Where should PATGuard 3 be installed?	3
Setup will install PATGuard 3 into the following folder.	
To continue, click Next. If you would like to select a different folder, click Brows	se.
C:\Program Files (x86)\Seaward\PATGuard 3 Brow	vse
At least 87.3 MB of free disk space is required.	
< Back Next >	Cancel

5. Click Next > to continue.



6. You will be asked to confirm you options. Click Install to continue.

j Setup - PATGuard 3	- 8
Ready to Install Setup is now ready to begin installing PATGuard 3 on your computer.	3
Click Install to continue with the installation, or click Back if you want to review or change any settings.	
Destination location: C:\Program Files (x86)\Seaward\PATGuard 3 Additional tasks: Additional Icons Create Desktop Icon	*
<	Þ.
< Back Instal	Cancel

7. You will be shown the progress of the installation.

j5 Setup - PATGuard 3	×
Installing Please wait while Setup installs PATGuard 3 on your computer.	3
Installing Visual Basic	
	Cancel

8. When the installation has finished, click Finish to launch PATGuard 3

15 Setup - PATGuard 3	
5	Completing the PATGuard 3 Setup Wizard Setup has finished installing PATGuard 3 on your computer. The application may be launched by selecting the installed icons. Click Finish to exit Setup.
PAT GUARD 5	Finish

9. PATGuard 3 will now start and the Login screen appear.

10. Click OK to launch PATGuard 3.

If you require more help, please contact us at https://www.seaward.com/cms/enquire/.