



# How to setup Desk TnT print format for Safetest Luminaire

1.

First Start up the Tester

- Select the '**Open File**' symbol key (3rd key down RHS)
- The tester will display a two options main header menu:
- The □ (arrow pointer) represents the active cursor.
- To select options use Up/Down (□↑) arrow to move cursor.
- To accept option (with cursor indicator) press **<enter>** (the carriage return symbol), **green 4th key down RHS**.

2.

Select Setup Tests/Data at Main Menu

- Go to Test routine.
- □ Setup Tests / Data.
- Enter a valid password using keypads (the tester maybe factory set with a blank password).
- Input Password (PW:).
- When a valid password is correctly identified the Display will show two options:
  - **Select Data / Password / Start option.**
    - Edit Test Sequence
    - Data / Password / Start
    - **Select the Setup Data Mode option.**
      - Setup Data Mode
      - Download / Delete
  - Select either **Print only** or **Print & Save Readings**.

- ☐ Print Only
- Save Only
- ☐ Print & Save Rdgs
- Omit Print & Save

3. Use up/down arrow to scroll ^ v for options, press <enter> to select.

4. User Must select Print Test & Tag format to print label to Desk TnT printer.

- ☐ Print Test & Tag

PC term / PATGuard

**Note: Do Not select PC term / PATGuard format when printing to Desk TnT printer.**

**After completing the setup configuration, press the 'Open File' symbol key to return to Main Menu.**

5. Notes on Setup Data Mode

This will allow four modes of Data processing for configuration:

- Print Only

This mode will send test results to printer port after each completed sequence.

- Save Only

This mode will only save to memory test results after each completed sequence.

- Print & Save readings

This mode will send data to printer port And save to memory test results taken after each completed sequence.

- Omit Print & Save

**Note:**

**Warning : This mode will not retain any of the test results or readings taken once test sequence is completed.**

If you require more help, please contact us at

<https://www.seaward.com/de/enquire/>.