The best downloadable PAT testers on the market.



Our world beating **Apollo**+ Series can be used to test in accordance with both the IET Code of Practice and BS EN50699. It now has a Wifi hotspot feature for remote data transfer via any mobile device in order to exchange data when testing in the field.

# Straightforward PAT testing with simple data management

Following in the footsteps of Seaward's long line of trusted PAT testers, the Apollo+ Series offer a comprehensive suite of electrical safety tests to enable any workplace appliance to be tested. The Apollo+ also enables point to point testing of fixed appliances.

# **Risk-based PAT testing**

The Apollo 600+ and 500+ have a built-in electrical risk assessment tool that can be used to easily determine a risk-based suggested retest period. For users who are responsible for recording other non-electrical tests or inspections such as fire extinguishers or ladders, the user-configurable test function enables this.

# Visual evidence for full traceability

Apollo 600+ has a built-in digital camera enabling images taken during visual inspections and risk assessments to be tagged against records in Seaward's PATGuard 3 software as evidence - making it the most comprehensive and traceable record-keeping system.

To see the **Apollo+** Series for yourself, request your live online demonstration today at **seaward.com/apolloplus** 

# Why buy the new Apollo+ Series?

- > Large on-board storage
- > High definition colour display
- Remote data transfer via hotspot to mobile device from field to office
- > Fixed appliance (point to point) testing
- User configurable tests- for nonelectrical tests and inspections e.g. fire extinguishers and PPE

# **Apollo+** Series **Users:**

- > Professional PAT Testers
- > Electrical Contractors
- > Facilities Managers
- > Operations Managers



The best downloadable PAT testers on the market.

# Total health and safety management

Apollo 600+ features a built-in universal risk assessment tool allowing hazards to be recorded, risk scores to be calculated and corrective actions to be planned and documented easily. For those who have responsibility for health and safety inspections outside of portable appliance testing, the Apollo 600+ also hosts onboard reports for fire detection and emergency lighting - making it an all-in-one solution for the future of health and safety management.

# Superb software for total traceability

Apollo+ Series instruments have large internal memories either 50,000, 10,000 or 2,000 slots (600+, 500+ and 400+ respectively) and an additional 2,000 images (600+ only). Their compatibility with Seaward's PATGuard 3 software means that complete test records, including images, can be easily managed on a PC.

Easily transfer data to a PC remotely using the Apollo Wifi hotspot function\* and any mobile phone tablet or computer or download results onto a USB flash drive (600+ only). Alternatively, transfer data directly using a USB lead when back at the office. Once downloaded to PATGuard 3, it is easy to keep track of the history of test and inspections, produce reports, certificates and invoices – offering total peace of mind and quicker, easier management of scheduling inspections and tests.

Time Manager 3 is an exciting software package, now included with PATGuard 3, and provides clear time management facilities. It's ideal for companies that manage off-site or remote testing staff and need to manage their business in a time efficient manner. It runs as part of PATGuard 3 software and provides clear graphical information on the user's activity such as number of tests taken, and time of tests.

Download a free trial at <a href="https://www.seaward.com/PG3">www.seaward.com/PG3</a>

# Scan and print QR codes

Seaward's new QR code data system allows more data to be stored in your PAT label barcode including; Asset ID, site, location, last and next test dates. Using Seaward's Test n Tag Elite 2 printer you can now print labels that include our unique QR data code, the Apollo 600+ and 500+ have the ability to read the data contained in the code via our new Bluetooth 2D Elite barcode scanner and populate the fields automatically for quicker retesting without the need for data upload.

With our new QR DATA Viewer app (available for both Android and iOS devices) you can share these benefits with your customers - the app allows end users to scan the labels and see the test information, they can then very easily share the data via email. This functionality allows duty holders and end users to keep better track of faulty items.

\*Wifi hotspot feature does not require internet connection

To see the **Apollo+** Series for yourself, request your live online demonstration today at **seaward.com/apolloplus** 

# Electrical Test Functions:

- Low current earth continuity test (with Zap circuit) guaranteeing accurate measurement
- > Insulation resistance
- > IEC lead test
- > Protective conductor current
- > Touch current
- > Load power/current
- > Alternative leakage current
- Point to point testing of earth continuity and insulation resistance
- > RCD test
- > Power socket test









The best downloadable PAT testers on the market.



# Apollo 600+

Apollo 600+ revolutionises safety management, with a built-in risk assessment tool for any workplace hazard and a variety of testing and inspection reports including portable appliance testing, fire detection and emergency lighting; Apollo 600+ offers an all-in-one solution to managing a risk-based approach to health and safety in any workplace, reducing the burden and ensuring compliance.

For complete traceability of results, including proof of visual inspection, the Apollo 600+ features an on-board camera, allowing photographs to be stored alongside risk assessments and other test and inspection data.

# 

# Apollo 500+

A great value 'plug and play' PAT tester with a comprehensive range of tests and advanced data transfer and storage features.

Designed to enable simple, professional and fast PAT testing, with remote data transfer, USB upload/download and a memory to store up to 10,000 complete test sets.

With point-to-point measurement, fast boot-up and a risk-based retest calculator to quickly determine suggested retest periods, Apollo 500+ is the ideal companion for highvolume testing.



# Apollo 400+

A comprehensive range of electrical safety tests ensure compliance with the IET 4th Edition Code of Practice, whilst remote data transfer and USB download makes data management easy and efficient.

The Apollo 400+ is ideal for mid-volume PAT testing where detailed records are required.

Streamline the PAT testing process further by using the Apollo 400+ with a compatible label printer, barcode scanner and PATGuard 3 software.

# Apollo 600+ Key Features:

- > On board camera
- > Upload data for faster retesting
- > Store 2,000 images
- > Store up to 50,000 appliance records
- > Ability to use (2D) QR codes
- > Built in universal and electrical risk assessment tools
- > Additional health and safety certificates

# Apollo 500+ Key Features:

- > Store up to 10,000 appliance records
- > Upload data for faster retesting
- > Ability to use (2D) QR codes
- Built in electrical risk
   assessment tool with suggested
   retest period calculator
- User configurable tests

   for non-electrical tests

   and inspections e.g. fire extinguishers and PPE

# Apollo 400+ Key Features:

- Store up to 2,000 appliance records
- > Printer Compatible
- Point to point measurment (Rpe & IR) - needs optional accessory
- > 25 User configurable electrical test/visual inspections sequences

To see the **Apollo+** Series for yourself, request your live online demonstration today at **seaward.com/apolloplus** 



The best downloadable PAT testers on the market.

# **Comparison Chart:**

General Features	600+	500+	400+
Battery & mains powered	•	•	•
Colour screen & QWERTY keypad	•	•	•
Large internal memory	up to 50,000 records and 2,000 photos	up to 10,000 records	up to 2,000 records
Bluetooth scanner & printer compatible	•	•	•
Password controlled user accounts	•	•	
Set up multiple user accounts with varying levels of privileges	•	•	
Clone facility to set up multiple testers	•	•	
Checkbox supplied as standard	•	•	
Test Inspection Features	600+	500+	400+
Auto-increment asset ID	•	•	
PAT Setup option to allow for custom menus	•	•	
Enter asset description after test using keypad or barcode scanner	•	•	•
Comprehensive electrical safety test features	•	•	•
Point to point measurement (Rpe & IR)	•	•	Optional accessory required
User configurable electrical test/visual inspection sequences	100	100	25
Jser set sites & locations	100	100	50
Risk based retest period calculator	•	•	
Jser definable comments lines against test records	4	4	
Configurable checklists for any workplace test or inspection (user tests)	•	•	
On-board camera	•		
Universal risk assessment	•		
Health & safety certificates	•		
Data Transfer	600+	500+	400+
D and 2D Scanner connectivity	•	•	Reads 1D Data Only
Read QR code (2D) labels with 2D scanner	•	•	
RFID reader connectivity	•		
Print Pass & Fail labels with 1D barcode	•	•	•
Print Pass & Fail labels with QR code (2D)	•	•	
Add your company logo to labels (on large 1D labels only)	•	•	
Select from various label formats to print	6	6	6
Download to PC via USB cable	•	•	•
Data Transfer via USB flash drive	•		
Filter results to be downloaded	•	•	•

To see the **Apollo+** Series for yourself, request your live online demonstration today at **seaward.com/apolloplus** 



The best downloadable PAT testers on the market.

# **Technical Specification:**

### **Earth Continuity (Rpe)**

Test Current: +/- 200mA DC Measurement Range:  $0.05\Omega$  to  $19.99\Omega$  Pass Value: User defined

# **Insulation Resistance (IR)**

Test Voltage: 500V / 250VDC @ 1mA nominal Measurement Range:  $0.10M\Omega$  to  $19.99M\Omega$  Pass Value: User defined

### **IEC Lead Test**

Test Voltage: 5VAC nominal Test: Live / Neutral Checks for o/c, s/c and crossed polarity

### **Protective Conductor Current/Load**

Test Voltage: Supply voltage, maximum load current 16A Measurement Range: 0.25mA to 19.99mA Pass Value: User defined

### **Touch Current**

Test Voltage: Supply voltage, maximum load current 16A Measurement Range: 0.10mA to 5.0mA Pass Value: User defined

# **Load Power/Current**

Test Voltage: 230V +10%, -15%, maximum load current 16A Test Duration: Programmable up to a maximum of 240s Measurement Range: 0.50A to 16.0A

# **Substitute (Alternative) Leakage Current**

Test Voltages: >25VAC <50VAC Measurement Range: 0.20mA to 19.99mA Pass Value: User defined

### **RCD Test**

Test Voltage: 230V +10%, -15%

Test Current: 30mA / 150mA rms sinusoidal

Display Range: 0ms to 2000ms

Test Method: Internal isolation to avoid tripping distribution board RCD

# **Power Socket Test**

Voltage Range: 207V - 253VAC Indicates configuration of voltage potential:-Line potential phase to earth Line potential phase to neutral Line potential neutral to earth

### General

Memory size (Apollo 600+): up to 50,000 records & 2,000 photos Memory size (Apollo 500+): up to 10,000 records Memory size (Apollo 400+): up to 2,000 records

Weight: 1.5kg

Dimensions: 230mm x 150mm x 100mm

Power Source: Mains or rechargeable battery pack

# What's in the box?

(Supplied as standard with Apollo+ Series)

	600+	500+	400+
Apollo Instrument	1	1	1
Professional Carry Case	1	1	
Test Lead 1.2m with Alligator Clip, Red	1	1	1
Test Lead 1.2m with Allogator Clip, Black	1	1	
IEC Extension Lead, 0.5m	1	1	1
Black Mains Lead	1	1	1
USB Download Lead	1	1	1
Apollo+ Check Box	1	1	
UKAS Calibration Certificate	1	1	1
Quick Start Guide	1	1	1

To see the **Apollo+** Series for yourself, request your live online demonstration today at **seaward.com/apolloplus** 





The best downloadable PAT testers on the market.

### **Part Numbers:** strumont Only

mistrument Omy
Apollo 600+
Apollo 500+

380A926 380A928 Apollo 400+ 380A930

Optional Accessory Kits (Supplied without Apollo+ Instrument)

Elite Accessory Bundle (includes Test n Tag Elite 2 Printer, Bluetooth 2D Scanner, 2x Elite durable labels 25mm, 2x Elite durable labels 75mm, Apollo Kit carry case, 110V test adaptor.

Pro Accessory Bundle 380A9911 (includes: Test n Tag Pro Printer, Bluetooth Barcode Scanner (1D), 2x Pro labels 25mm, 2x Pro labels 75mm,

Apollo Kit carry case, 110V test adaptor. Optional Accessory Kits (Supplied with Apollo+ Instrument)

Apollo 600+ with Elite Bundle 380A9893 Apollo 600+ with Elite Bundle and 1 year PATGuard 3 software 380A9894 Apollo 500+ with Elite Bundle 380A9899 Apollo 500+ with Elite Bundle and 1 year PATGuard 3 software 380A9900 Apollo 400+ with Elite Bundle 380A9906 Apollo 400+ with Elite Bundle and 1 year PATGuard 3 software 380A9907

Apollo 600+ with Pro Bundle 380A9890 Apollo 600+ with Pro Bundle and 1 year PATGuard 3 software 380A9891 Apollo 500+ with Pro Bundle 380A9896 Apollo 500+ with Pro Bundle and 1 year PATGuard 3 software 380A9897 Apollo 400+ with Pro Bundle 380A9902 Apollo 400+ with Pro Bundle and 1 year PATGuard 3 software 380A9903

**Optional Accessories** 

Test n Tag Elite 2 Bluetooth printer 339A989 Test n Tag Elite 2 Durable Label Rolls (52x74mm) approx. 120 off 339A9491 339A9490 Test n Tag Elite 2 Durable Label Rolls (52x25mm) approx. 304 off 339A980 Test n Tag Pro Bluetooth printer Roll of Large White Label Rolls (52x74mm) approx. 130 off 339A946 Roll of Small White Label Rolls (52 x 25mm) approx. 350 off 339A947

Bluetooth 2D Elite Scanner 339A925 Bluetooth 1D Barcode Scanner 339A923

110V Test Adaptor (for Rpe and IR) 270A076 3 Phase Leakage Adaptor, Star 5 pin 16A (for Rpe and Leakage) 391A920 3 Phase Leakage Adaptor, Star 5 pin 32A (for Rpe and Leakage) 391A910 209A910 3 Phase Adapter, Delta 4 pin 16A (for Rpe & IR) 3 Phase Adapter, Star 5 pin 16A 415V (for Rpe & IR) 209A911 3 Phase Adapter, Delta 4 pin 32A 415V (for Rpe & IR) 2094912 3 Phase Adapter, Star 5 pin 32A 415V (for Rpe & IR) 209A913

Apollo+ Series Checkbox 380A953 Apollo+ Series USB Download Lead 396A976 300A002 Apollo+ Series 0.5m IEC Test Lead Apollo+ Series Red and Black Test Lead Set 380A951 380A982 Apollo+ Series Red Test Lead Apollo+ Series Black Test Lead 380A983

380A019 **Apollo+ Series Spare Battery** 380A9910 Apollo+ Series Battery Charger Apollo+ Series Kit Bag 71G109 Apollo+ Series Carrying Case 380A952

**PATGuard 3 Software** 

PATGuard 3 Elite 1 Year Licence 400A910 PATGuard 3 Elite Outright Purchase

Download a 30 day free trial of PATGuard 3 at www.seaward.com/PG3

Seaward offer a range of PAT testing courses, go to <a href="www.seaward.com/training">www.seaward.com/training</a> for more information.

Warranty
2 year warranty (subject to terms and conditions, available at <a href="https://www.seaward.com/warranty24">www.seaward.com/warranty24</a>



380A9912







