POWERTEST 1557

Multi function installation tester



Thanks to a clever bit of design, we have included a cordless probe for use with the tester, meaning you can hold the tester and see the results at the same time. Weighing in at a mere 900 grams, it's light too. And it can do any test that you require at the turn of a knob, including Earth Continuity, Insulation (100v, 250v, 500v), Non-trip Loop Impedance, Line Impedance, RCD trip line, RCD trip current and voltage / frequency measurements.

Key Features

Comprehensive testing features

Comprehensive 17th edition and Part-P testing features allow for a multitude of tests including: Earth Continuity, Insulation (100v, 250v, 500v), Non-trip Loop Impedance, Line Impedance, RCD Trip current, and Voltage/Frequency measurement.

unique cordless probe

Makes testing a breeze as it allows you a free hand to hold your tester - therefore you can view your results, as you're testing.

Non-tripping loop

Measure loop impedance without tripping RCD's.

Smallest and lightest in its class It fits in the palm of your hand and won't weigh

you down.

PowerSolution Users

- Electrical Contractors
- Electrical Engineers
- Training Institutions



Web: www.seaward.co.uk Email: sales@seaward.co.uk

Seaward

Bracken Hill, South West Industrial Estate, Peterlee, SR8 2SW Tel: +44 (0) 191 5863511 Fax: +44 (0) 191 5860227

POWERTEST 1557 SPECIFICATIONS

SPECIFICATION

Earth Continuity

Test Current Display Range Resolution Test Lead Compensation Live Circuit Detection >200mA 0.00ohms - 199ohms 0.01ohms maximum Null lead resistance 0.00ohms - 10.00ohms Test inhibit if >30V detected

Insulation Resistance

Test Voltage Display Range Resolution Live Circuit Detection 100V, 250V, 500V 0.05Mohms – 199Mohms 0.01Mohms maximum Test inhibit if >30V detected

Loop/Line Impedance

Supply Voltage Test Current Display Range Resolution Loop Impedance Line Impedance PFC/PSC Range 195 – 253V/440V, 45Hz – 65Hz 15mA (non tripping for RCD protected circuits) 0.010hms - 20000hms 0.010hms maximum Phase to Earth Phase to Neutral/Phase to Phase 0 – 26kA

RCD Trip Time

Supply Voltage Test Currents	195 – 253V, 45 – 65Hz 10, 30, 100, 300, 500mA
Trip Time Ranges	0ms – 2000ms at 1/2 Irn
	0ms – 300ms at Irn general
	0ms – 500ms at Irn selective
	0ms – 40ms at 5x Irn
Auto Test	Auto sequence for 1/2 Irn, Irn and 5x Irn at 0° and 180° $$
RCD Type	General (G), Selective (S), Pulsed (A), AC (AC)

RCD Trip Current (Ramp Test)

 Supply Voltage
 195 – 253V, 45 – 65Hz

 Test Currents
 10, 30, 100, 300, 500mA

 Ramp Current Range
 1/2 Irn to 1.1 Irn

Voltage/Frequency Measurement

Display Range	0-440V
Resolution	1V
Frequency Measuring Range	45 – 65Hz
Compliance	IEC 61010-1 300V CAT III, EN 61557
Dimensions	260 x 100 x 55
Weight	950g
Power Supply	6 x AA Alkaline (supplied), 6 xx AA NiMH
	Rechargeable (Optional)

PowerTest 1557 Part No. 328A910



Web: www.seaward.co.uk Email: sales@seaward.co.uk

Supplied with

- 2 year warranty
- 6 x 1.5V cells LR6 type AA alkaline batteries
- Test lead, 1.5M 13A UK plug to Red, Black, Green 4mm shrouded safety plugs
- Alligator Clips: Red, black, green
- Test lead, set 1.5M Red, Black, Green 4mm shrouded safety plugs to Red, Black, Green 4mm shrouded safety test probes
- Red, cordless, 4mm shrouded safety test probe

Optional Extras

Services:

Service & Calibration

Jump Start

Seaward

Bracken Hill, South West Industrial Estate, Peterlee, SR8 2SW **Tel:** +44 (0) 191 5863511 **Fax:** +44 (0) 191 5860227