



SEAWARD
ELECTRICAL SAFETY TESTING
& MEASURING.

How many sample points does the PV200/210 take when I-V curve tracing?

Our tester is an “auto sensing” type instrument. If it sees the plot point values are stable during the curve trace and consistent, it takes less sample points and makes testing quicker than having a set number of sample points like some other I-V curve tracers. If the trace looks unstable, the tester will take more sample points to plot an accurate curve. Maximum number of sample points is 120.

If you require more help, please contact us at

<https://www.seaward.com/cms/enquire/>.